

Wireless Noise Canceling Stereo Headset

Беспроводные стереонаушники с функцией шумоподавления

шумоподавления

https://rd1.sony.net/help/mdr/whch710n/h_zz/	Reference Guide GB 參考指南 CT 참고 설명서 KR Справочник RU دليل مرجعي AR
©2020 Sony Corporation Printed in Vietnam https://www.sony.net/	5 0 1 3 8 9 2 3 2 * (1) 

WH-CH710N

DIGITAL NC Bluetooth

English

Wireless Noise Canceling Stereo Headset

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Do not subject the batteries to extreme low temperature conditions that may result in overheating and thermal runaway.

Do not dismantle, open or shred secondary cells or batteries.

Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight. In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.

Secondary cells and batteries need to be charged before use. Always refer to the manufacturer's instructions or equipment manual for proper charging instructions. After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance. Dispose of properly.

This equipment has been tested and found to comply with the limits set out in the EMC regulation using a connection cable shorter than 3 meters.

Do not use, store, or leave in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

Do not use at a dangerous place unless the surrounding sound can be heard.

The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately and consult your nearest Sony dealer. In particular, be careful in the following cases:

- When using the unit around a sink, etc. Be careful that the unit does not fall into a sink or container filled with water.
- When using the unit in the rain or snow, or in humid locations
- When using the unit while you are sweaty
- If you touch the unit with wet hands, or put the unit in the pocket of a damp article of clothing, the unit may get wet.

For details on the effect of contact to the human body from the mobile phone and other wireless devices connected to the unit, refer to the instruction manual of the wireless device.

Never insert the USB plug when the main unit or charging cable is wet. If the USB plug is inserted while the main unit or charging cable is wet, a short circuit may occur due to the liquid (tap water, seawater, soft drink, etc.) attached to the main unit or charging cable as well as to foreign matter, and cause an abnormal heat generation or malfunction.

This product (including accessories) has magnets(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

This product has magnets. Placing cards with magnets in the vicinity of the product may affect the magnetism of the card and render it unusable.

Note on static electricity
Static electricity accumulated in the body may cause mild tingling in your ears. To reduce the effect, wear clothes made from natural materials, which suppress the generation of static electricity.

This product has magnets. Placing cards with magnets in the vicinity of the product may affect the magnetism of the card and render it unusable.

Note on static electricity
Static electricity accumulated in the body may cause mild tingling in your ears. To reduce the effect, wear clothes made from natural materials, which suppress the generation of static electricity.

Complies with IMDA Standards DB00353

TRA
REGISTERED No: ER79121/20
DEALER No: DA0096946/12

Precautions

On Bluetooth® communications

- Bluetooth wireless technology operates within a range of about 10 m. The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
- Bluetooth communications may not be possible, or noise or audio dropout may occur under the following conditions:
 - When there is a person between the unit and the Bluetooth device. This situation may be improved by positioning the Bluetooth device so that it faces the antenna of the unit.
 - When there is an obstacle, such as a metal object or a wall, between the unit and the Bluetooth device.
 - When a Wi-Fi device or microwave oven is in use, or microwaves are emitted near the unit.
 - Compared to use indoors, use outdoors is subjected little to signal reflection from walls, floors, and ceilings, which results in audio dropout occurring more frequently than use indoors.

The antenna is built into the unit as indicated by the dotted line in the illustration (Fig. 1). The sensitivity of the Bluetooth communications can be improved by removing any obstacles between the connected Bluetooth device and the antenna of this unit.

- Bluetooth and Wi-Fi (IEEE802.11b/g/n) devices use the same frequency (2.4 GHz). When using the unit near a Wi-Fi device, electromagnetic interference may occur, resulting in noise, audio dropout, or the inability to connect. If this happens, try performing the following remedies:
 - Establish a connection between the unit and the Bluetooth device when they are at least 10 m away from the Wi-Fi device.
 - Turn off the Wi-Fi device when using the unit within 10 m of the Wi-Fi device.
 - Position the unit and the Bluetooth device as near as possible to each other.

- Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices. Turn off this unit and other Bluetooth devices in the following locations, as it may cause an accident:
 - in hospitals, near priority seating in trains, locations where inflammable gas is present, near automatic doors, or near fire alarms.

- The audio playback on this unit may be delayed from that on the transmitting device, due to the characteristics of Bluetooth wireless technology. As a result, the sound may not be in sync with the image when viewing movies or playing games.
- This product emits radio waves when used in wireless mode. When used in wireless mode on an airplane, follow flight crew directions regarding permissible use of products in wireless mode.

- The unit supports security functions that comply with the Bluetooth standard as a means of ensuring security during communication using Bluetooth wireless technology. However, depending on the configured settings and other factors, this security may not be sufficient. Be careful when communicating using Bluetooth wireless technology.
- Sony shall assume no responsibility for any damages or loss resulting from information leaks that occur when using Bluetooth communications.

- Connection with all Bluetooth devices cannot be guaranteed.
 - Bluetooth devices connected with the unit must comply with the Bluetooth standard prescribed by Bluetooth SIG, Inc., and must be certified as compliant.
 - Even when a connected device complies with the Bluetooth standard, there may be cases where the characteristics or specifications of the Bluetooth device make it unable to connect, or result in different control methods, display, or operation.
 - When using the unit to perform hands-free talking on the phone, noise may occur depending on the connected device or the communication environment.
- Depending on the device to be connected, it may require some time to start communications.

If sound skips frequently during playback

- The situation may be improved by changing the wireless playback quality settings or fixing the wireless playback mode to SBC on the transmitting device. For details, refer to the operating instructions supplied with the transmitting device.
- When listening to music from a smartphone, the situation may be improved by closing unnecessary apps or restarting the smartphone.

On the use of calling apps for smartphones and computers

- This unit supports normal incoming calls only. Calling apps for smartphones and computers are not supported.

On charging the unit

- This unit can be charged using USB only. A computer with a USB port or a USB AC adaptor is required for charging.
- Be sure to use the supplied USB Type-C cable.

- When charging, the unit cannot be turned on and the Bluetooth and noise canceling functions cannot be used.
- If the unit is not used for a long time, the rechargeable battery may become depleted quickly. The battery will be able to hold a proper charge after it is discharged and recharged several times.
- When storing the unit for a long time, charge the battery once every six months to prevent over-discharge.
- If the rechargeable battery becomes depleted extremely quickly, it should be replaced with a new one. Please contact your nearest Sony dealer for a battery replacement.

If the unit does not operate properly

- Follow the procedure below to reset the unit (Fig. 1).
- Press the ○ and NC/AMB buttons simultaneously while the unit is charging. The unit is reset. When the unit is reset, the pairing information in the unit is not deleted.
- If the problem persists even after the unit is reset, perform the procedure below to initialize the unit. Disconnect the USB Type-C cable and turn off the unit. Press and hold the ○ and ■ buttons simultaneously for at least 7 seconds. The indicator (blue) flashes 4 times, the unit is initialized, and the unit is reset to factory settings. After the unit is initialized, all pairing information is deleted.
- After the unit is initialized, it may not connect to your iPhone or computer. If this happens, delete the pairing information of the unit from the iPhone or computer, and then pair them again.

On the noise canceling function

- The noise canceling function senses external ambient noise (such as the noise inside a vehicle or the sound of air conditioning inside a room) with built-in microphones, and produces an equal-but-opposite sound that cancels out the ambient noise.
- The noise canceling effect may not be pronounced in a very quiet environment, or some noise may be heard.
- The noise canceling function works for noise in the low frequency band primarily. Although noise is reduced, it is not canceled completely.
- When you use the unit in a train or a car, you may occur depending on street conditions.
- Mobile phones may cause interference and noise. Should this occur, locate the unit further away from the mobile phone.
- Depending on how you wear the unit, the noise canceling effect may vary or a beeping sound (howling) may occur. If this happens, take off the unit and put it back on again.
- Do not cover the microphones of the unit with your hands or other objects. Doing so may prevent the noise canceling function or the Ambient Sound Mode from working properly, or may cause a beeping sound (howling) to occur. If this happens, take your hands or other object off of the microphones of the unit (Fig. 1).

Notes on wearing the unit

- Because the headphones achieve a tight seal over the ears, forcibly pressing them against your ears or quickly pulling them off can result in eardrum damage. When wearing the headphones, the speaker diaphragm may produce a click sound. This is not a malfunction.

Other notes

- Do not subject the unit to excessive shock.
- When you use the unit as wired headphones, use the supplied headphone cable only. Make sure that the headphone cable is firmly inserted.
- The Bluetooth function will not work with a mobile phone, depending on the signal conditions and the surrounding environment.
- Do not apply weight or pressure to the unit for long periods, including when it is stored, as it may cause deformation.
- If you experience discomfort while using the unit, stop using it immediately.
- The earpads may be damaged or deteriorate with long-term use and storage.

Cleaning the unit

- When the outside of the unit is dirty, clean it by wiping with a soft dry cloth. If the unit is particularly dirty, soak a cloth in a dilute solution of neutral detergent, and wring it well before wiping. Do not use solvents such as thinner, benzene, or alcohol, as they may damage the surface.
- If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

Replacement parts: earpads
Please consult your nearest Sony dealer for information about replacement parts.

Location of the serial number label
See Fig. 1

Specifications

Headset

Power source:
DC 3.7 V: Built-in Lithium-ion rechargeable battery
DC 5 V: When charged using USB

Operating temperature:
0 °C to 40 °C

Rated power consumption:
2.0 W

Usage hours:
When connecting via the Bluetooth device

- Music playback time: Max. 35 hours (NC ON), Max. 40 hours (Ambient Sound Mode), Max. 45 hours (NC OFF)
- Communication time: Max. 35 hours (NC ON), Max. 35 hours (Ambient Sound Mode), Max. 40 hours (NC OFF)
- Standby time: Max. 35 hours (NC ON), Max. 40 hours (Ambient Sound Mode), Max. 40 hours (NC OFF)

When connecting via the headphone cable with NC ON: Max. 50 hours
Note: Usage hours may be shorter depending on the Codec and the conditions of use.

Charging time:
Approx. 7 hours
(About 60 minutes of music playback is possible after 10 minutes charging.)
Note: Charging and usage hours may be different depending on the conditions of use.

Charging temperature:
5 °C to 35 °C

Mass:
Approx. 223 g

Impedance:
72 Ω (1 kHz) (when connecting via the headphone cable with the unit turned on)
33 Ω (1 kHz) (when connecting via the headphone cable with the unit turned off)

Sensitivity:
94 dB/mW (when connecting via the headphone cable with the unit turned on)
100 dB/mW (when connecting via the headphone cable with the unit turned off)

Frequency response:
7 Hz - 20,000 Hz (JEITA) (when connecting via the headphone cable with the unit turned on)

Included items:
Wireless Noise Canceling Stereo Headset (1)
USB Type-C® cable (USB-A to USB-C®) (approx. 20 cm) (1)
Headphone cable (approx. 1.2 m) (1)

Communication specification

Communication system:

Bluetooth Specification version 5.0

Outputs:

Bluetooth Specification Power Class 2

Maximum communication range:

Line of sight approx. 10 m*

Frequency band:

2.4 GHz band (2,400 MHz - 2,483.5 MHz)

Compatible Bluetooth profiles†:

A2DP / AVRCP / HFP / HSP

Supported Codec†:

SBC / AAC

Support range (A2DP):

20 Hz - 20,000 Hz (Sampling frequency 44.1 kHz)

- The actual range will vary depending on factors such as obstacles between devices, magnetic fields around a microwave oven, static electricity, reception sensitivity, antenna's performance, operating system, software application, etc.
- Bluetooth standard profiles indicate the purpose of Bluetooth use for communications between devices.
- Codec: Audio signal compression and conversion format

Design and specifications are subject to change without notice.

System requirements for battery charge using USB

USB AC adaptor

A commercially available USB AC adaptor capable of supplying an output current of 0.5 A (500 mA) or more

Trademarks

- iPhone and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
- Android is a trademark of Google LLC.
- The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license.
- Product Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.
- USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
- Other trademarks and trade names are those of their respective owners.

Notes on the License

This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of copyright for the software. Please access the following URL and read the contents of the license.
https://rd1.sony.net/help/mdr/sl/20/

Disclaimer regarding services offered by third parties

Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

關於智慧型手機和電腦的通話應用程式之使用

- 本機僅支援一般來電。不支援智慧型手機和電腦的通話應用程式。

關於為本機充電

- 本機僅能以USB充電。需要具備USB接埠的電腦，或USB交流電源供應器以充電電腦，或USB交流電源供應器以充電充電。
 - 請務必使用隨附的USB Type-C連接線。
 - 充電時本機電池不能開啟，也無法使用Bluetooth和防偽功能。
 - 如果充電長時間不使用，充電電池的電力可能衰退至極低。電池放電和重新充電電次之後，就能保留當量電量。如果要長時間存放本機，請每兩週對電池充電一次，以免過度放電。
 - 如果充電電池的電力耗盡極為迅速，應以新電池更換。請洽詢附近的Sony經銷商以更換電池。
- 如果本機的操作不正常**
- 請按照下列程序以復設本機（圖1）。在本機充電時，同時按下○和NC/AMB按鈕。本機重設時，不會刪除本機內的配對資訊。
 - 如果本機重設後問題仍然存在，請執行下列程序以初始化本機。
 - 拆除USB Type-C連接線，並關閉本機電源。
 - 同時按住○和■按鈕至少3秒。指示燈（藍色）會閃爍4次，本機初始化化，接著本機會重設為原廠設定。初始化本機時，所有的配對資訊將被刪除。
 - 本機初始化後，可能無法與iPhone或電腦中的本機配對資訊，然後重新配對它們。

關於防偽功能

- 防偽功能以內建的麥克風偵測外部環境聲音（例如，車輛內的聲音，或房間內空調機的聲音），然後產生相等但相反的聲音以抵消防偽功能。
- 在非常安靜的場所中，防偽的效果可能不顯著，或者可能會出現一些噪音。
- 防偽功能主要能減少低頻段的聲音。雖能以降低噪音，但無法完全消除。
- 如果您在汽車或汽車專用車庫使用本機，根據街道狀況，可能會出現噪音。
- 行駛時可能會引發干擾和噪音。這種情形發生時，請將本機離開駕駛座電話。
- 根據本機本機的工作時間，防偽效果可能會有差異，或是可能會聽到提示音（喇叭聲）。當這種情況發生時，請取下本機，然後再戴上。
- 請勿用手或其他物品蓋住本機的麥克風。此舉可能會降低防偽功能或導致防偽模式無法正常運作，或可能產生提示音（喇叭聲）。當這種情況發生時，請將手或其他物品移離本機的麥克風（圖1）。

配對模式的注意事項

- 因為耳機在耳朵上形成密封狀態，如果朝耳朵吹氣，或快速拉下耳機，可能會損壞耳機，嚴重時，隔聲膜片可能會發出喀喀聲。這並不是故障。

其他注意事項

- 請勿將耳機承受過度撞擊。
- 將本機用作有線耳機時，請確保隨附的耳機連接線，請務必將耳機連接線牢固地插入。
- 視訊訊號狀況與周圍環境而定，Bluetooth功能可能無法使用。
- 請勿長時間對本機施加重量或壓力，包括在它存放時，否則可能造成變形。
- 如果您在使用本機後發生不適，請立即停止使用本機。
- 耳墊可能會因長時間的使用與存放而損壞或劣化。

繁體中文

無線防噪立體聲耳機

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自增加頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述禁制規定，係指電磁波對作業之無線電通信。低功率射頻電機須符合電波干擾限制之干擾值。

請勿將本機放置於密閉的空間內，例如車廂或內裝的櫥櫃內。

請勿將電池（安裝或更換電池組或電池）長時間暴露於熱濕的環境下，例如日照、火焰，或其他類似之狀況。

經測試，本設備符合EMC規定中使用3米以下連接線的規格。

僅適用於台灣

廢電池請回收

請勿在大量濃煙、粉塵、煙塵或蒸氣的場所使用，儲存或放置於上述地點，或者放置在高溫場所，例如：接近火源處，或車內受陽光直射處等。

高音量可能會影響您的聽力。

在走路、駕駛或操作機器時，請勿使用本耳機，否則可能發生交通事故。

除非可以聽到周圍的聲音，否則請勿在危險性的地方使用本耳機。

本耳機不防水。如果水或液體物進入耳機，可能產生火災或電擊。如果水或液體物進入耳機，請立即停止使用，並諮詢附近的Sony經銷商。請特別記得要遵循下列預防措施。

在水槽等物附近使用時，請小心勿使耳機掉入裝有水的水槽或容器中。

在雨中或雪中使用，或在潮濕的地方使用時，如在您游泳時使用，如果以濕的手觸碰耳機，或者耳機置於潮濕物品的口袋中，耳機可能會受損。

關於連接耳機的行動電話或其他無線裝置，請參閱該裝置的說明手冊。

當主機或充電線潮濕時，切勿插入USB插頭。如果主機或充電線潮濕的狀況下插入USB插頭，可能會因主機或充電線上黏附的潮濕（汗水或水），導致主機或充電線物造成短路，並導致異常發熱或故障。

本產品（含配件）有磁力，可能會干擾心律調節器。用於積聚水治療的可調式引流線或其他醫療器材。請勿將本產品放在此類醫療器材使用時的附近。如果您使用任何醫療醫療器材，請在使用本產品前諮詢該器材的說明手冊。

本產品具有磁體，將具有磁性的卡片放置在產品附近可能會影響卡片磁性，導致無法使用。

靜電注意事項

身體累積的靜電可能會使您的雙耳稱刺癢，為減少這種現象，請穿戴由天然材質製成的衣物，這種衣物能抑制靜電的產生。

預防措施

關於Bluetooth®通訊

- Bluetooth無線技術的適用範圍約為10 m，最大通訊距離可能因障礙物（人、金屬物品、牆面等）或電磁干擾而不同。
- 在下列狀況下，Bluetooth通訊也許不可行，或可能出現噪音或音質失真：
 - 本機和Bluetooth裝置之間有障礙物，以干擾彼此狀況。
 - 本機和Bluetooth裝置之間有障礙物，例如金屬物品或牆壁時。
 - Wi-Fi裝置或微波爐在使用中，或本機附近有微波在放射時。
 - 根據於室內使用，戶外使用可能會稍微受到牆壁、地板和天花板的訊號反射，使通訊速率的狀況比室內使用來得多。
 - 天氣條件建成本機時，如雷電或雷暴所引起（圖1），移動無線裝置時，可能會與本機天線之間的任何障礙物，可以改善Bluetooth通訊的靈敏度。

- Bluetooth與Wi-Fi（IEEE802.11b/g/n）裝置同時使用，或同時使用Wi-Fi裝置，可能會對附近使用本機時，可能產生電磁干擾，導致噪音、音訊失真，或無法連線。當這種情況發生時，請執行下列補救措施：
 - 在本機與Bluetooth裝置距離Wi-Fi裝置至少10 m時，在本機與Bluetooth裝置之間建立連線。
 - 在距離Wi-Fi裝置10 m內使用本機時，請離開Wi-Fi裝置的充電座。
 - 將本機與Bluetooth裝置盡量靠近彼此放置。

- Bluetooth裝置所放射的微波可能會影響電子醫療裝置的運作，為避免意外發生，在下列位置關閉的本機和其他Bluetooth裝置：
 - 在醫院內，火車內的博覽座附近、有可燃性氣體的其他地點、自動門或火災警報器附近。
 - 由於Bluetooth無線技術的特性，本機的通訊接收可能會延遲於無線裝置，因此在此觀看影片或玩遊戲時，聲音可能沒有與影像同步。
 - 本產品以無線模式使用時會發射無線電波。

- 本產品在飛機上以無線模式使用時，請從從機組人員關於允許以無線模式使用產品的指示。
- 本機僅符合Bluetooth標準的安全功能；這些功能以Bluetooth無線技術進行通訊時，能確保安全性。但是，依據配對的設定和其他因素而定，這項安全性未必充分。使用Bluetooth無線技術通訊時請小心。
- Sony對於使用Bluetooth通訊時，因資訊洩漏而產生的任何損傷或損失恕不負責。不保證所有與Bluetooth裝置有關連性。
- Bluetooth無線技術的規格，符合Bluetooth SIG, Inc.規定的Bluetooth標準，而且必須獲得認證。
- 即使接連的裝置符合Bluetooth標準，Bluetooth裝置的規格或規格可能無法使用其無法運作，或產生不同的控制方法，顯示或操作。
- 以本機連接手機的免持通話時，依連接的裝置或通訊環境不同而定，可能會產生延遲。
- 依要接連的裝置而定，可能會需要一些時間才能開始通訊。

播放時聲音經常會斷斷續續

- 在傳輸裝置上變更無線播放品質設定或將無線播放模式固定為SBC，可能可以改善此狀況。如需詳細資料，請參閱傳輸裝置隨附的使用說明書。
- 如果傳輸裝置播放手機的音樂，透過關閉不必要的應用程式或重新啟動智慧型手機，可能可以改善此狀況。

關於智慧型手機和電腦的通話應用程式之使用

- 本機僅支援一般來電。不支援智慧型手機和電腦的通話應用程式。

關於為本機充電

- 本機僅能以USB充電。需要具備USB接埠的電腦，或USB交流電源供應器以充電電腦，或USB交流電源供應器以充電充電。
- 請務必使用隨附的USB Type-C連接線。
- 充電時本機電池不能開啟，也無法使用Bluetooth和防偽功能。
- 如果充電長時間不使用，充電電池的電力可能衰退至極低。電池放電和重新充電電次之後，就能保留當量電量。如果要長時間存放本機，請每兩週對電池充電一次，以免過度放電。
- 如果充電電池的電力耗盡極為迅速，應以新電池更換。請洽詢附近的Sony經銷商以更換電池。

如果本機的操作不正常

- 請按照下列程序以復設本機（圖1）。在本機充電時，同時按下○和NC/AMB按鈕。本機重設時，不會刪除本機內的配對資訊。
- 如果本機重設後問題仍然存在，請執行下列程序以初始化本機。
 - 拆除USB Type-C連接線，並關閉本機電源。
 - 同時按住○和■按鈕至少3秒。指示燈（藍色）會閃爍4次，本機初始化化，接著本機會重設為原廠設定。初始化本機時，所有的配對資訊將被刪除。
 - 本機初始化後，可能無法與iPhone或電腦中的本機配對資訊，然後重新配對它們。

關於防偽功能

- 防偽功能以內建的麥克風偵測外部環境聲音（例如，車輛內的聲音，或房間內空調機的聲音），然後產生相等但相反的聲音以抵消防偽功能。
- 在非常安靜的場所中，防偽的效果可能不顯著，或者可能會出現一些噪音。
- 防偽功能主要能減少低頻段的聲音。雖能以降低噪音，但無法完全消除。
- 如果您在汽車或汽車專用車庫使用本機，根據街道狀況，可能會出現噪音。
- 行駛時可能會引發干擾和噪音。這種情形發生時，請將本機離開駕駛座電話。
- 根據本機本機的工作時間，防偽效果可能會有差異，或是可能會聽到提示音（喇叭聲）。當這種情況發生時，請取下本機，然後再戴上。
- 請勿用手或其他物品蓋住本機的麥克風。此舉可能會降低防偽功能或導致防偽模式無法正常運作，或可能產生提示音（喇叭聲）。當這種情況發生時，請將手或其他物品移離本機的麥克風（圖1）。

配對模式的注意事項

- 因為耳機在耳朵上形成密封狀態，如果朝耳朵吹氣，或快速拉下耳機，可能會損壞耳機，嚴重時，隔聲膜片可能會發出喀喀聲。這並不是故障。

其他注意事項

- 請勿將耳機承受過度撞擊。
- 將本機用作有線耳機時，請確保隨附的耳機連接線，請務必將耳機連接線牢固地插入。
- 視訊訊號狀況與周圍環境而定，Bluetooth功能可能無法使用。
- 請勿長時間對本機施加重量或壓力，包括在它存放時，否則可能造成變形。
- 如果您在使用本機後發生不適，請立即停止使用本機。
- 耳墊可能會因長時間的使用與存放而損壞或劣化。

清潔本機

• 本機外部軟垢時，請用柔軟的乾布擦拭清潔。如果本機特別髒，請將布浸入稀釋的中性清潔劑溶液中，充分攪拌後擦拭，請勿使用洗潔精，苯或酒精等溶劑，否則可能會損壞表面。

• 如果您有任何關於本機的疑問或問題而本說明書中並未提及，請洽詢附近的Sony經銷

